

OUTERIMPACT

SMITH & WESSON VICTORY - M.R.A. (Modular RedDot Adapter) Mounting Instructions

Utilize a certified Gun Smith to install adapter. It is possible to install adapter if a Gun Smith is not accessible, but it is recommended that adapter be installed by a Gun Smith.

WARNING: Never remove or install components on a gun before ensuring the gun is not loaded and the chamber is clear.

Step 1: Locate bag marked "MNT HDWR" and remove the 8-32 screw.















Step 2: Remove existing sight from the Smith & Wesson Victory.

STEP 3: "Rack" the slide and lock it in the "open" position. *The slide will interfere with installation if closed.*

STEP 4: Slide plastic insert under the "hook" located on the Smith & Wesson Victory slide.

STEP 5: Align Outerimpact plate so the screw hole is showing. Place 8-32 screw in hole and tighten.

STEP 6: Torque screw to 25 in/lbs

MOUNTING PATTERNS:	SIGHT Manufacture	SIGHTS Model	SCREWS USED
The RED circles indicate locations for 2 included alignment pins  			
The BLACK circles indicate locations for mounting screws ---- Torque Screws to 12 IN/LBS			
	VORTEX	VIPER	M3 x 8mm 
	BURRIS	FAST FIRE 3	
	BURRIS	FAST FIRE 2	M3 x 6mm 
DOCTOR	MRDS		
	INSIGHT	MRDS	M3 X 6mm 
	EOTECH	MRDS	
	VORTEX	VENOM	M3 X 6mm 
	TRIJICON	RMR	#6 SCREWS 
	LEUPOLD	Delta Point Delta Point Pro	SIGHT SUPPLIED SCREWS WORK
	VORTEX	RAZOR	M4 SCREWS 
	SIG SAUER	ROME03	
	CMORE	RTS & STS	

UTILIZE LIQUID THREAD LOCKER UPON FINAL INSTALLATION OF ALL THREADED FASTENERS.